


TO  
IRRIGATION CONTROLLER  
CAGE ASSEMBLY  
120 VOLTS 2-WIRE W/ GROUND



## NOTES:

1. GROUT BOX AT CONDUIT ENTRANCE. RESTORE ANY GROUT DAMAGED BY INSTALLATION.
2. CONNECT #8 CONDUCTOR TO CONDUIT BOND WIRE (FOR GRC INSTALLATIONS)  
OR TO GREEN GROUND WIRE (FOR PVC INSTALLATIONS.)
3. INSULATE HOT/NEUTRAL SPLICES AS FOLLOWS:  
COVER WITH 2-LAYERS RUBBER TAPE-FILLING VOIDS.  
APPLY 1-LAYER 1/2 LAPPED PVC TAPE  
APPLY 1-LAYER FRICTION TAPE & COAT WITH A ELECTRICAL INSULATING COATING (SKOTCHKOTE OR EQUAL.)